

Previously known as: Crusader Flex 42474



Heat



Heavy Duty

Heat-resistant full-length gloves, offering complete protection and added comfort

- **Specialized protection:** ActivArm® 42-474 industrial gloves possess a full-length heat barrier and can confidently handle dry, hot objects up to 250°C/480°F
- **Elevated comfort:** These heat-resistant gloves' two-piece construction features no outseams, enhancing finger comfort and flexibility, while a sweat-absorbent nonwoven felt liner limits perspiration
- **Assured durability:** Their bonded nitrile coating grants them additional snag, puncture, cut and abrasion resistance
- **Enhanced grip:** ActivArm® 42-474 heat-resistant work gloves also provide excellent grip in dry or oily conditions
- **Reduced health risks:** These heavy-duty gloves contain no asbestos, eliminating all related health risks



Industries

- Automotive
- Chemical
- Food processing (indirect contact only)

Applications

- Press injection molding
- Handling molded structural parts
- Testing
- Welding

Previously known as: Crusader Flex 42474

Key Features

- **Felt insulation and heat barrier:** Hot and dry handling (250°C/480°F)
- **Outseam-free two-piece construction:** Enhanced comfort and flexibility
- **Bonded nitrile coating:** Snag, puncture, abrasion and cut resistance

Performance Standards & Regulatory Compliance

ANSI/ISEA 105-2024



EN388: 2016



2241B

EN 407



X2XXXX

Specifications

BRAND STYLE	DESCRIPTION	Gauge	SIZE	LENGTH	PACKAGE
ActivArm® 42-474	Liner Material: Non-Woven Polyester, Polycotton Cuff Style: Gauntlet	N/A	9, 10	343-356 mm; 13.5-14 inches	12 pairs/bag, 6 bags/carton

For additional information visit us at www.ansell.com, or call us at

Europe, Middle East & Africa Region

Ansell Healthcare Europe NV
Riverside Business Park
Blvd International, 55
1070 Brussels, Belgium
T: +32 (0) 2 528 74 00
F: +32 (0) 2 528 74 01

Latin America & Caribbean Region

Ansell Commercial Mexico S.A. de C.V.
Blvd. Bernardo Quintana No. 7001-C,
Q7001 Torre II,
Suites 1304, 1305 y 1306,
Col. Centro Sur, c.p. 76079
Queretaro, Qro. Mexico
T: +52 442 248 1544 / 248 3133

North America Region

Ansell Healthcare Products LLC
111 Wood Avenue South,
Suite 900
Iselin, NJ 08830, USA
T: +1 800 800 0444
F: +1 800 800 0445

Canada

Ansell Canada
105 Lauder
Cowansville, QC J2K 2K8
Canada
T: +1 800 363 8340
F: +1 800 267 3551

Australia

Ansell Limited
Level 3, 678 Victoria Street,
Richmond, Vic, 3121
Australia
T: +61 1800 337 041
F: +61 1800 803 578

Asia Pacific Region

Ansell Global Trading Center
(Malaysia) Sdn Bhd
Prima 6, Prima Avenue
Block 3512, Jalan Teknokrat 6
T: +603 8310 6688
F: +603 8310 6699