

MODEL NO.:T-9234

INDOOR/ OUTDOOR THERMOMETER

+ FUNCTION:

- °F/°C SELECTABLE, MAX/MIN (F/C) MEMORY RECALLING



+ FEATURES:

- INDOOR/OUTDOOR TEMPERATURE DISPLAY
- TEMPERATURE UNIT °F/°C SELECTABLE
- MAX/MIN (°F/°C) MEMORY RECALLING
- ALARM CLOCK WITH SNOOZE FUNCTION
- 12/24 HOUR FORMAT
- TRIPLE ROW TEMPERATURE DISPLAY
- 3M SENSOR WIRE WITH PROBE FOR OUTDOOR TEMPERATURE MEASUREMENT
- FLIP OUT STAND AT BACK OF UNIT
- LOW BATTERY INDICATOR
- 2 X 1.5 VOLTS "A76" SIZE (LR44, G13) OR EQUIVALENT BATTERIES

+ SPECIFICATION:

MEASUREMENT RANGE:

- -50°C ~ +70°C OR -58°F ~ +158°F

ACCURACY:

- $\pm 1^{\circ}\text{C}$ OR $\pm 1.8^{\circ}\text{F}$ IN THE RANGE OF -20°C ~ +70°C OR -4°F ~ +158°F, OTHERWISE MORE THAN $\pm 1^{\circ}\text{C}$ OR $\pm 1.8^{\circ}\text{F}$

RESOLUTION:

- $\pm 0.1^{\circ}$ FOR WHOLE RANGE

+ °F /°C FUNCTION:

- PRESS °F/°C TO SELECT DESIRABLE TEMPERATURE UNIT.

+ MAX/MIN

- PRESS MAX / MIN TO RECALL MAXIMUM AND MINIMUM TEMPERATURE TESTED. THE UNIT RETURNS TO REAL TIME MODE AUTOMATICALLY AFTER 5 SECONDS. CONTINUE TO PRESS FOR 3 SECONDS. THE STORED TEMPERATURE WILL BE CLEARED.